

R/O Filter Change Instructions Kinetico QuickChange & Kinetico K5

- □ Turn off feed line to R/O. If you do not have a K5, shut off the feed line to the tank. If you have a pump attached to your R/O, unplug it.
- □ Turn on drinking water faucet to depressurize and leave on until the water only trickles out.
- Remove the used prefilter cartridge by twisting it a ¼ turn counter-clockwise so that the ears are able to disengage from the head. Firmly pull the cartridge side to side to help disengage it
- □ Fill prefilter (either purple or yellow) with water from your kitchen tap.
- □ Insert new filter by lining up the cartridge ears and push it into the head of the R/O until it is fully sealed. Twist the cartridge ¼ turn clockwise to lock it into place.
- □ Line up post filter (either orange or blue) into the corresponding spot. For K5 only, make sure that the Puremometer pin and gear inside line up so that the pin at the front of the R/O moves up.
- NOTE: Do not remove the membrane, which is the canister in the middle between the two filters. Please bring in a water sample to test if the membrane needs to be changed.
- □ Turn off faucet.
- \Box Slowly turn on feed line(s).
- □ Turn on the R/O faucet for one minute to remove sediment or carbon fines from the new filters. NOTE: It is normal for air to spit out of the faucet when it is running. It is recommended to put a towel over the faucet to eliminate water splash.
- □ If your R/O is connected to your refrigerator, fill 2-3 glasses of water to remove any air or sediment in the water.
- RECOMMENDED: Flush the tank 2 times by turning on faucet allowing water to drain. Repeat to flush a second time.
- □ That's it! Enjoy your water, and please contact us if you have any problems!